



362M18

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar


A 362M18
ENGINE GROUP



Page A 362M18		ENGINE GROUP		
Position	Article	Quantity	Notes	Kit
1	516 86 45-01	1		
2	516 86 51-01	1		
3	516 53 74-01	4		
4	516 34 61-01	1		
5	516 86 58-01	1		
6	516 33 83-01	1		
7	516 34 62-01	2		
8	516 86 53-01	1		
9	516 86 54-01	2		
10	521 67 27-01	1		
12	516 86 66-01	1		
13	516 86 61-01	2		
14	516 86 64-01	1		
15	521 63 37-01	1		
16	516 86 77-01	1		
17	521 52 12-01	2		
18	521 84 01-01	1		
19	521 52 18-01	1		
20	516 07 11-01	4		
21	544 25 87-01	2		
22	516 86 84-01	1		
23	516 37 71-01	1		
24	516 87 59-01	1		
25	521 09 82-01	2		
26	521 09 83-01	1		
27	521 05 72-01	2		
28	516 31 34-01	1		
29	516 74 17-01	2		
30	521 63 39-01	1		
31	516 28 31-01	1		
32	516 31 39-01	2		
33	516 14 78-01	1		
34	516 87 70-01	1		
35	516 87 71-01	1		
36	521 04 81-01	2		
37	516 61 02-01	1		
38	516 61 03-01	1		
39	521 26 06-01	1		
40	521 39 77-01	1		
41	516 89 16-01	1		
42	516 87 83-01	1		
43	521 84 31-01	1		
44	516 23 11-01	1		
45	521 84 32-01	1		
46	521 84 33-01	1		
47	516 54 98-01	1		
48	502 84 38-01	1		
49	504 55 49-01	1		
50	502 84 37-01	1		
51	502 84 35-01	1		
52	502 84 32-01	1		
53	516 34 89-01	1		
54	521 13 28-01	4		
55	573 94 68-01	1		


Page A		362M18	ENGINE GROUP		
Position	Article	Quantity	Notes	Kit	
56	516 87 92-01	1			
57	521 11 63-01	1			
58	521 11 64-01	1			
59	521 11 65-01	1			
60	505 05 23-01	1			
61	529 31 42-01	1			
62	516 35 02-01	1			
63	521 36 20-01	1			
64	516 36 13-01	1			
65	516 34 69-01	1			
66	516 11 40-01	2			
67	516 36 16-01	1			
68	544 26 35-01	1			
69	516 19 99-01	1			
70	516 86 85-01	6			

B 362M18
CARBURETOR




Page B		362M18	CARBURETOR	
Position	Article	Quantity	Notes	Kit
1	516 54 36-01	1		
8	516 54 38-01	1		
9	516 54 39-01	1		
10	516 52 58-01	1		
11	521 36 04-01	1		
12	516 59 77-01	1		
13	516 52 36-01	1		
14	516 16 06-01	1		
15	516 16 07-01	1		
16	516 54 37-01	1		
17	505 05 64-01	1		
18	506 61 28-01	2		
19	506 61 69-01	1		
20	516 52 41-01	1		
21	544 36 50-01	1		
22	516 59 76-01	1		
23	516 54 40-01	4		
24	516 87 94-01	1		
25	516 52 46-01	1		

C 362M18
BLOWER GROUP




Page C 362M18		BLOWER GROUP		
Position	Article	Quantity	Notes	Kit
1	574 34 40-01	1		
2	529 28 68-01	1		
3	516 86 90-01	12		
4	520 81 05-01	1		
5	521 13 83-01	3		
6	521 14 12-01	1		
7	516 13 54-01	1		
8	516 87 02-01	2		
9	520 96 86-01	2		
10	516 86 98-01	1		
11	516 87 09-01	1		
12	521 11 49-01	4		
13	573 93 16-01	1		
14	516 86 90-01	4		
15	573 93 18-01	1		
16	521 14 28-01	2		
17	573 97 20-01	1		
18	526 47 67-01	4		
19	516 88 42-01	2		
20	516 88 43-01	1		
21	511 74 33-01	1		
22	516 88 45-01	2		
23	516 87 57-01	2		
24	516 87 58-01	4		
25	511 96 73-01	2		
26	516 87 82-01	1		
27	521 52 51-01	1		
28	521 11 41-01	1		
29	502 84 29-01	1		
30	544 27 63-01	1		
31	520 96 86-01	1		
32	544 27 65-01	1		
33	544 27 66-01	1		
34	544 27 67-01	1		
35	544 27 68-01	1		
36	544 27 69-01	1		
37	544 27 70-01	1		
38	521 51 96-01	1		
39	544 27 72-01	2		
40	504 55 46-01	1		
41	544 27 74-01	1		
42	544 27 75-01	1		
43	544 27 76-01	1		
44	516 87 54-01	4		
45	521 68 06-01	1		
46	516 89 90-01	1		
47	521 67 24-01	1		
48	506 61 54-01	1		
49	506 61 53-01	1		
50	544 27 26-01	1		
51	504 11 79-01	1		
52	516 87 98-01	1		
53	520 95 35-01	1		
54	516 26 21-01	1		
55	521 11 56-01	2		
56	516 17 82-01	1		
57	574 21 74-01	1		

D 362M18
SPRAY GROUP



Page D 362M18		SPRAY GROUP		
Position	Article	Quantity	Notes	Kit
2	573 94 62-01	1		
3	529 31 22-01	1		
4	521 12 97-01	1		
5	520 81 34-01	2		
6	521 13 21-01	1		
7	521 13 20-01	1		
8	521 84 37-01	2		
9	521 84 39-01	1		
10	520 81 69-01	1		
11	516 29 07-01	1		
12	521 84 40-01	1		
13	521 84 38-01	2		
14	521 84 36-01	1		
16	516 88 53-01	1		
17	521 84 34-01	1		
18	573 93 29-01	2		
19	516 89 04-01	2		
20	516 89 05-01	4		
21	516 88 24-01	2		
22	516 88 25-01	1		
23	516 88 26-01	1		
24	516 88 28-01	1		
25	516 89 04-01	2		
26	573 93 36-01	1		

E 362M18
SPRAY EQUIPMENT, TOOLS



Page E 362M18		SPRAY EQUIPMENT, TOOLS		
Position	Article	Quantity	Notes	Kit
1	521 83 96-01	1		
2	526 34 33-01	1		
3	526 34 34-01	1		
4	521 14 88-01	1		
5	521 14 90-01	1		
7	520 82 20-01	1		
9	520 78 43-01	2		
10	516 29 07-01	3		
11	520 78 44-01	1		
14	521 13 09-01	1		
16	521 13 11-01	1		
17	516 13 47-01	1		
18	521 13 12-01	1		
19	521 13 13-01	1		
20	521 13 14-01	1		
21	516 10 59-01	1		
22	521 13 15-01	1		
24	516 89 49-01	1		
25	520 82 79-01	1		
26	506 61 50-01	1		
27	521 14 91-01	1		
28	521 14 92-01	1		
29	521 14 93-01	1		
30	521 14 94-01	1		
31	520 92 19-01	2		